LAPORAN KEGIATAN PRAKTIKUM PENGENALAN SISTEM PENGEMBANGAN OS DENGAN PC SIMULATOR 'BOCHS'



Disusun oleh:

NAMA : Gita Juli Hartanti

NIM: L200190256

KELAS: G

Langkah Kerja

Menuju ke direktori kerja.

- 1. Jalankan program command promt atau cmd. Maka akan muncul tampilan sebagai berikut.
 - C:\Windows\System32\cmd.exe

```
Microsoft Windows [Version 10.0.18362.1016]
(c) 2019 Microsoft Corporation. All rights reserved.
C:\>_
```

- 2. Selanjutnya ketik perintah 'cd os' lalu <ENTER>.
 - C:\Windows\System32\cmd.exe

```
Microsoft Windows [Version 10.0.18362.1016]
(c) 2019 Microsoft Corporation. All rights reserved.

C:\>cd os

C:\OS>
```

3. Selanjutnya ketik perintah 'dir' maka akan muncul seperti di bawah ini.

```
C:\Windows\System32\cmd.exe
Microsoft Windows [Version 10.0.18362.1016]
(c) 2019 Microsoft Corporation. All rights reserved.
C:\>cd os
 :\OS>dir
 Volume in drive C has no label.
 Volume Serial Number is 188B-5780
 Directory of C:\OS
25/09/2020 10:25
                        <DIR>
25/09/2020 10:25
25/09/2020 10:20
                        <DIR>
                        <DIR>
                                          Bochs-2.3.5
25/09/2020 10:25
                                       0 cd
25/09/2020 10:20
                        <DIR>
                                         Dev-Cpp
                          1.096.291 i386.pdf
17/12/2008
              00:08
                        <DIR>
26/09/2020 14:31
                                         LAB
                                846.920 pcasm-book.pdf
17/12/2008 00:07
 17/12/2008 01:44
                                      86 Setpath.bat
                576.512 winima81.exe
5 File(s) 2.659.809 bytes
5 Dir(s) 151.454.896.128 bytes free
13/12/2008 14:12
C:\0S>
```


4. Untuk menjalankan file setpath klik 'setpath' tekan <ENTER>

```
C:\OS>setpath
C:\OS>Path=C:\OS\Dev-Cpp\bin;C:\OS\Bochs-2.3.5;c:\OS\Perl;C:\Windows;C:\Windows\System32
C:\OS>
```


5. Lalu masuk ke direktori kerja pada C:\OS\LAB\LAB1

```
C:\OS>cd lab
C:\OS\LAB>cd lab1
C:\OS\LAB\LAB1>_
```

6. Untuk membuka file tersebut, masukkan perintah pada 'COMMAND PROMPT' dengan cara ketik 'notepad boot.asm' klik <ENTER>. Maka akan muncul tampilan seperti di bawah ini.



7. Selanjutnya tutup notepad, bukalah direktori kerja 'C:OS\LAB\LAB1' lalu klik 'Notepad M' tekan tombol 'TAB' sehingga muncul 'Notepad Makefile' lalu klik <ENTER>.



8. Buka 'COMMAND PROMPT' ketik make fp. Disk, jika tidak ada kesalahan akan muncul seperti gambar dibawah ini.

```
C:\OS\LAB\LAB1>make fp.disk
nasm boot.asm -o boot.bin -f bin
dd if=boot.bin of=floppya.img
rawwrite dd for windows version 0.5.
Written by John Newbigin <jn@it.swin.edu.au>
This program is covered by the GPL. See copying.txt for details
1+0 records in
1+0 records out

C:\OS\LAB\LAB1>
```

9. Ketik 'del floppy.img /P' lalu tekan 'Y' lalu <ENTER>

```
C:\OS\LAB\LAB1>del floppya.img /P
C:\OS\LAB\LAB1\floppya.img, Delete (Y/N)? Y
```

10. Masukkan perintah 'dir' maka akan muncul gambar seperti di bawah. Setelah itu klik 'bximage'

```
C:\OS\LAB\LAB1>dir
 Volume in drive C has no label.
Volume Serial Number is 188B-5780
Directory of C:\OS\LAB\LAB1
26/09/2020 18:38
26/09/2020 18:38

26/09/2020 18:38

10/09/2019 16:19

15/12/2008 16:17

14/12/2008 12:02

26/09/2020 18:35

15/12/2008 00:47
                     <DIR>
                            10.235 bochsout.txt
                              1.628 bochsrc.bxrc
                            14.365 boot.asm
                               512 boot.bin
                                 78 dosfp.bat
14/12/2008 11:45
                             7.966 kernel.asm
                               227 Makefile
15/12/2008 16:21
                            44 s.bat
15/12/2008 12:20
                                 35.055 bytes
               8 File(s)
               2 Dir(s) 151.450.845.184 bytes free
C:\OS\LAB\LAB1>bximage
 ______
                                bximage
                  Disk Image Creation Tool for Bochs
        $Id: bximage.c,v 1.32 2006/06/16 07:29:33 vruppert Exp $
Do you want to create a floppy disk image or a hard disk image?
Please type hd or fd. [hd] 🗕
```

(Membuat file image floppy tahap-1)

11. Klik 'fd' lalu tekan <ENTER>

```
C:\OS\LAB\LAB1>bximage

bximage

Disk Image Creation Tool for Bochs

$Id: bximage.c,v 1.32 2006/06/16 07:29:33 vruppert Exp $

Do you want to create a floppy disk image or a hard disk image?

Please type hd or fd. [hd] fd

Choose the size of floppy disk image to create, in megabytes.

Please type 0.16, 0.18, 0.32, 0.36, 0.72, 1.2, 1.44, 1.68, 1.72, or 2.88.

[1.44]
```

(Membuat file image floppy tahap-2)

```
:\OS\LAB\LAB1>bximage
 bximage
       Disk Image Creation Tool for Bochs
$Id: bximage.c,v 1.32 2006/06/16 07:29:33 vruppert Exp $
Do you want to create a floppy disk image or a hard disk image?
Please type hd or fd. [hd] fd
Choose the size of floppy disk image to create, in megabytes.
Please type 0.16, 0.18, 0.32, 0.36, 0.72, 1.2, 1.44, 1.68, 1.72, or 2.88.
[1.44]
 will create a floppy image with
 cyl=80
 heads=2
 sectors per track=18
 total sectors=2880
 total bytes=1474560
What should I name the image?
[a.img] 🕳
```

(Membuat file image foppy tahap-3)

12. Untuk memberikan nama file, ketiklah 'floppya.img' lalu <ENTER>

```
:\OS\LAB\LAB1>bximage
                                                bximage
           Disk Image Creation Tool for Bochs
$Id: bximage.c,v 1.32 2006/06/16 07:29:33 vruppert Exp $
Do you want to create a floppy disk image or a hard disk image?
Please type hd or fd. [hd] fd
Choose the size of floppy disk image to create, in megabytes.
Please type 0.16, 0.18, 0.32, 0.36, 0.72, 1.2, 1.44, 1.68, 1.72, or 2.88.
 [1.44]
  will create a floppy image with
   cyl=80
   heads=2
   sectors per track=18
total sectors=2880
   total bytes=1474560
What should I name the image?
[a.img] floppya.img
Writing: [] Done.
I wrote 1474560 bytes to floppya.img.
The following line should appear in your bochsrc:
floppya: image="floppya.img", status=inserted
(The line is stored in your windows clipboard, use CTRL-V to paste)
Press any key to continue
```

13. Pastikan bahwa nama file imagenya adalah 'floppy.img' dengan memasukkan perintah 'dir' lalu <ENTER>. Jika belum ada maka Anda harus mengulangi proses dari awal dengan memanggil program 'bximage'.

```
C:\OS\LAB\LAB1>dir
 Volume in drive C has no label.
 Volume Serial Number is 188B-5780
 Directory of C:\OS\LAB\LAB1
26/09/2020 20:58
                    <DIR>
26/09/2020 20:58
                   <DIR>
26/09/2020 19:00 1.474.560 a.img
10/09/2019 16:19
                           10.235 bochsout.txt
15/12/2008 16:17
                           1.628 bochsrc.bxrc
14/12/2008 12:02
                           14.365 boot.asm
26/09/2020 18:51
                              512 boot.bin
15/12/2008 00:47
                              78 dosfp.bat
26/09/2020 20:58
14/12/2008 11:45
                       1.474.560 floppya.img
14/12/2008 11:45
                           7.966 kernel.asm
                              227 Makefile
15/12/2008 16:21
15/12/2008 12:20
                               44 s.bat
             10 File(s) 2.984.175 bytes
              2 Dir(s) 151.412.658.176 bytes free
C:\OS\LAB\LAB1>
```

14. Jalankan PC-Simulator dari 'COMMAND PROMPT' klik perintah 'DosFp'. Maka akan muncul gambar seperti dibawah ini. Setelah A:\> klik 'Format B:' Lalu klik <ENTER> 2X tetapi beri jeda.

👺 Bochs for Windows - Display Reset SUSPEND Power (1) Copyright (C) Microsoft Corp. 1986-1993. All rights reserved. Drive R: = Driver OSLAB unit 0 A:\>Format B: Insert new diskette for drive B: and press ENTER when ready... Checking existing disk format. Formatting 1.44M Format complete. Volume label (11 characters, ENTER for none)? 1,457,664 bytes total disk space 1,457,664 bytes available on disk 512 bytes in each allocation unit. 2,847 allocation units available on disk. Volume Serial Number is 3953-1CF5 Format another (Y/N)?N Format another (Y/N)?n A:\> CTRL + 3rd button enables mouse B: HD:0-M CD:0-S NUM CAPS SCRL C:\OS\LAB\LAB1>Dosfp C:\OS\LAB\LAB1>cd "..\..\Bochs-2.3.5\dos" C:\OS\Bochs-2.3.5\dos>..\bochs -q -f bochsrc2.txt 0000000000i[APIC?] local apic in initializing Bochs x86 Emulator 2.3.5 Build from CVS snapshot, on September 16, 2007 _____] reading configuration from bochsrc2.txt 00000000000i[installing win32 module as the Bochs GUI 00000000000i[00000000000i[] using log file bochsout.txt

15. Tutup PC-Simulator dengan klik tombol power. Copy 512 byte data bootsektor ke dalam file terpisah. Buka 'Command Prompt' ketik 'dd if=floppy.img of=boots.bin count=1' lalu <ENTER>

```
C:\OS\LAB\LAB1>Dosfp
C:\OS\LAB\LAB1>cd "..\..\Bochs-2.3.5\dos"
C:\OS\Bochs-2.3.5\dos>..\bochs -q -f bochsrc2.txt
00000000000i[APIC?] local apic in initializing
-----
                 Bochs x86 Emulator 2.3.5
        Build from CVS snapshot, on September 16, 2007
._____
0000000000i[ ] reading configuration from bochsrc2.txt
00000000000i[
             ] installing win32 module as the Bochs GUI
           ] using log file bochsout.txt
00000000000i[
# In bx_win32_gui_c::exit(void)!
______
Bochs is exiting with the following message:
[WGUI ] POWER button turned off.
C:\OS\Bochs-2.3.5\dos>cd "C:\os\lab\lab1"
C:\OS\LAB\LAB1>dd if=floppya.img of=boots.bin count=1
rawwrite dd for windows version 0.5.
Written by John Newbigin <jn@it.swin.edu.au>
This program is covered by the GPL. See copying.txt for details
1+0 records in
1+0 records out
C:\OS\LAB\LAB1>
```


16. Ketik 'tdump boots.bin' lalu <ENTER>

```
C:\OS\LAB\LAB1>tdump boots.bin
Turbo Dump Version 5.0.16.12 Copyright (c) 1988, 2000 Inprise Corporation
                     Display of File BOOTS.BIN
000000: EB 3C 90 4D 53 57 49 4E 34 2E 31 00 02 01 01 00 .<.MSWIN4.1....
                                 12 00 02 00 00 00 00 00 ...@.....
000010: 02 E0 00 40 0B F0 09 00
                                 1C 53 39 4E 4F 20 4E 41 .....)..S9NO NA
000020: 00 00 00 00 00 00 29 F5
000030: 4D 45 20 20 20 20 46 41
                                 54 31 32 20 20 20 33 C9 ME FAT12
                                 78 00 C5 76 00 1E 56 16 ....{...x..v..V. 4E 02 B1 0B FC F3 A4 06 U."..~..N.....
000040: 8E D1 BC FC 7B 16 07 BD
000050: 55 BF 22 05 89 7E 00 89
                                 38 4E 24 7D 20 8B C1 99 ...|.E..8N$} ...
000060: 1F BD 00 7C C6 45 FE 0F
000070: E8 7E 01 83 EB 3A 66 A1
                                 1C 7C 66 3B 07 8A 57 FC .~...:f..|f;..W.
000080: 75 06 80 CA 02 88 56 02
                                 80 C3 10 73 ED 33 C9 FE u....V...s.3..
000090: 06 D8 7D 8A 46 10 98 F7
                                 66 16 03 46 1C
                                                13 56 1E ...}.F...f..F..V.
                                 60 89 46 FC 89 56 FE B8 .F....v.`.F..V..
0000A0: 03 46 0E 13 D1 8B 76 11
                                 C3 48 F7 F3 01 46 FC 11 ....^...H...F..
0000B0: 20 00 F7 E6 8B 5E 0B 03
0000C0: 4E FE 61 BF 00 07 E8 28
                                 01 72 3E 38 2D 74 17 60 N.a...(.r>8-t.
                                 74 3D 4E 74 09 83 C7 20 ....}..at=Nt...
0000D0: B1 0B BE D8 7D F3 A6 61
0000E0: 3B FB 72 E7 EB DD FE 0E
                                 D8 7D 7B A7 BE 7F 7D AC ;.r.....}{....}
0000F0: 98 03 F0 AC 98 40 74 0C
                                       13 B4 ØE BB Ø7 ØØ .....@t.Ht.....
                                 E6 BE 80 7D EB E1 CD 16 .....}....}....
81 7D 8B 7D 1A 8D 45 FE ^.f.....}....
000100: CD 10 EB EF BE 82 7D EB
000110: 5E 1F 66 8F 04 CD 19 BE
000120: 8A 4E 0D F7 E1 03 46 FC
                                 13 56 FE B1 04 E8 C2 00 .N....F..V.....
                                 50 06 53 6A 01 6A 10 91 r...p.RP.Sj.j..
000130: 72 D7 EA 00 02 70 00 52
000140: 8B 46 18 A2 26 05 96 92
                                 33 D2 F7 F6 91 F7 F6 42 .F..&...3.....B
                                 E8 C0 CC 02 0A CC B8 01 ...v....
000150: 87 CA F7
                76 1A 8A F2 8A
                                 42 8B F4 8A 56 24 CD 13 ..~..u..B...V$...
000160: 02 80 7E 02 0E 75 04 B4
000170: 61 61 72 0A 40 75 01 42
                                 03 5E 0B 49 75 77 C3 03 aar.@u.B.^.Iuw..
000180: 18 01 27 0D 0A 49 6E 76
                                 61 6C
                                       69 64 20 73 79 73 ..'.. Invalid sys
000190: 74 65 6D 20 64 69 73 6B
                                 FF 0D 0A 44 69 73 6B 20 tem disk...Disk
0001A0: 49 2F 4F 20 65 72 72 6F
                                 72 FF 0D 0A 52 65 70 6C I/O error...Repl
0001B0: 61 63 65 20 74 68 65 20
                                 64 69 73 6B 2C 20 61 6E ace the disk, an
                                 72 65 73 73 20 61 6E 79 d then press any
0001C0: 64 20 74 68 65 6E 20 70
                                 49 4F 20 20 20 20 20 20 key....IO
0001D0: 20 6B 65 79 0D 0A 00 00
0001E0: 53 59 53 4D 53 44 4F 53
                                 20 20 20 53 59 53 7F 01 SYSMSDOS SYS..
0001F0: 00 41 BB 00 07 60 66 6A 00 E9 3B FF 00 00 55 AA .A...`fj..;...U.
C:\OS\LAB\LAB1>
```


17. Untuk melihat isi file 's.bat' masukkan perintah 'type s.bat' lalu <ENTER>

```
C:\OS\LAB\LAB1>type s.bat
..\..\bochs-2.3.5\bochs -q -f bochsrc.bxrc
C:\OS\LAB\LAB1>
```

18. Masukkan perintah 's' lalu klik <ENTER>



19. Ketik 'Dosfp' pada command prompt lalu pada windows bochs masukan perintah 'A:\>format B:/S' lalu <ENTER>



20. Matikan PC-Simulator dengan klik power. Ketik 'S' lalu <ENTER>

